


# PA-1700TX High Temperature Muffle Furnace



**PAWA DENTAL**

# Contents

1. Introduction -----	P. 2
2. Technical Specifications -----	P. 2
3. Furnace Structure -----	P. 2
4. Instruction of the 708P Intelegant Temperature Controller --	P. 3
5. Setting Procedure of 708P Temperature Controller -----	P. 4
6. Installation Procedures -----	P.10
7. Instruction for Quick Start -----	P.11
8. Maitainace and Cautions -----	P.12
9. Trouble Shooting for typical Problems -----	P.12
10. Attention -----	P.12
11. Circuit diagram -----	P.13
12. Packing list -----	P.14
13. Eligible certificate -----	P.14

# Instructions and Operation Manual for PA-1700TX High Temperature Muffle Furnace

Thank you for purchasing MTI PA-1700 High Temperature Muffle Furnace. To avoid any misuse and damage, please read the operation instruction carefully before operation


## 1. Introduction

PA-1700TX high temperature muffle furnace uses MoSi<sub>2</sub> rod as heating element. Max. Temperature inside furnace can be reached at 1700 °C. The furnace temperature profile can be set up by 51 segments and run automatically by the 708P type temperature controller. It is excellent for material research, ceramic research labs.

## 2. Technical Specifications

Item	Unit	Parameter
Max.Power	KW	1
Voltage	V	AC 220 single phase 50/60 Hz
Max. Temperature	°C	1700
Continuous working temperature	°C	1600
Suggested heating rate	°C/min	≤ 10
Temperature accuracy controlled	°C	± 1 °C
Heating element		MoSi <sub>2</sub>
Connection of heating element		Series connection
Thermal Couple		B type Pt-Rh to Pt-Rh
Heat capacity inside chamber	KWH	≤ 80
Dimension of inside chamber	mm	100L x 100W x 110 H
Dimension of outside	mm	330 L x 320W x 480 H
Net Weight	Kg	38

## 3. Furnace Structure



PA-1700TX high temperature furnace uses high quality fiber Alimina as refractory material, and selects MoSi<sub>2</sub> as heating element. Temperature control panel comes with power lock, power and circuit open indicator, as well as output voltage and current meter. It is evry easy to operate and observe furnace working condition.

#### 4. Instruction of the 708 Inteligent Temperature Controller.

##### (1) Main Feature:

- The 708P temperature controller uses advanced AI intelligent adjustment method, no over shooting, and has auto tune function.
- Both of Input and output employ digital calibration system and insure accurate and stable measurement.
- Measuring accuracy: 0.2% in full scale.
- Alarm function: Up limit and input open circuit.
- 51 segments programmable.
- Power off protection. In the case power off or other disturbing, input data can be saved via smart EPROM IC to ensure continuously running once power resume
- Universal switching power: 85V -264V AC, 50 – 60 Hz
- Power consumption: ≤ 5W

##### (2) Temperature Controller Connections:

There are 20 connectors in backside temperature controller. The connection is as Fig 1:








Fig. 1

##### (3) Indication of Front Panel of Temperature Controller

On Front Panel of Yudian 708P temperature controller, there are several signs and icons such as OUT, AL1, AL2, AUX, PV, SV, , , , and , which indicate the meaning as the Figure 2




Fig.2

## 5. Setting Procedure of 708P Temperature Controller

Before running the furnace, you must plug in 220-240V AC power.

Install thermal couples on the back of the furnace and make sure connection correctly (blue wire connecting with negative; brown wire connecting with positive, Fig.3 )



Figure 3

### (1) Starting State of Display of Controller Panel

When turn power on, controller display show the model No (708P) of controller, software version first, Several seconds later, controller will display temperature condition. PV shows real temperature, and SV shows setting temperature.


If “SV” flashing, and shows “ **Stop**”, it means that control program is at stop state; If “SV” shows “ **Hold**”, means that program is at the pause stage.



Fig. 4

### (2) Switching Function of Display

Under starting state of temperature display as Fig. 4, e.g. the panel can be switched to program setting function and parameter setting function by touch key:

Touch  key for one second, PV will show “ Step” and SV show Step # (Usually show 1) as Fig. 5



Touch  key for once again, PV will show the setting time in the step, and SV shows the time that has run in this step.



Fig.5



Fig.6

Touch  key for two second under “starting state”, Display will enter parameter setting function as Fig 7, ( PV shows M5, and SCV shows 289.7)

Please don't change any parameter unless you understand what parameter is. The all parameter has been preset according to our experience. Next chapter will explain how to change “Parameters “ Please be advised that

*If no any key touch action on the panel, Display will return to “Starting State “automatically. And all revised data will be saved.*



Fig.7

### (3) Setting Temperature Control Program

In order to set temperature control program, you must switch display panel from “starting state” to Fig. 5 state.



Then touch Key  for one second, the Panel enter temperature program setting stage. On the display, ( as Fig. 8) PV shows first segment for temperature SV shows Initial temperature value



Fig. 8

Then touch Key , program enters holding time ( as Fig. 9)










Fig. 9

PV show the segment number for time

SV shows time setting ( Minutes ) in this segment

By touch key , and , you can increase or decrease the value to be set. Yudian 708 controller allows you to set one temperature profile up to 51 segments

By touch key  and uses key   you can get in next segment for temperature or time setting.

During program setting, by touching  for two seconds, you can return to previous set to make revise.

By touching  key first, then touch  key, you can exist program setting.

If no key operation for 30 seconds, display exists program setting and return to “starting state”.

### (4) Example for Setting Temperature Control Program with 6-segment Profile

For a complicated temperature control profile, we strongly suggest you to make drawing as Fig. 10, then make form as table 1 to list all data in every segment.

Fig. 10 is the temperature profile that we would like to set.








Fig. 10

According this profile, you shall list all segments in the following table: **Table 1**

Segment #	Symbol in Panel	Data to be In-put	Meaning in the program
1	<b>C 01</b>	<b>0</b>	Initial Temperature
2	<b>t 01</b>	<b>50</b>	Ramping time from 0 – 400 °C Average Heating rate is 8 °C /min
3	<b>C 02</b>	<b>400</b>	Target temperature value to first heating stage ( 400 °C )
4	<b>t 02</b>	<b>10</b>	Soaring time at 400 °C stage
5	<b>C 03</b>	<b>400</b>	Temperature value at the heating flat
6	<b>t 03</b>	<b>120</b>	Second Heating time from 400 -1600 °C Average heating rate is 10 °C /min
7	<b>C 04</b>	<b>1600</b>	Target temperature value to peak heating stage ( 1600 °C )
8	<b>t 04</b>	<b>30</b>	Soaring time at 1600 °C stage
9	<b>C 05</b>	<b>1600</b>	Temperature value at peak heating flat
10	<b>t 05</b>	<b>100</b>	Cooling time to 500 °C Cooling rate is 1110 °C /min
11	<b>C 06</b>	<b>500</b>	Target temperature to be cooled ( 500 °C )
12	<b>t 06</b>	<b>-121</b>	Program end, Out-put power off. Furnace cooling naturedly. ( t 06 = -120 is an order to stop running .

Using 4 keys of , , ,  enter data listed the above table into controller separately , then , you finish one temperature control program finish


Please be noted that “ t xx “ is time value for XX segment. It can be set from 1- 9999 minutes. However, if “ t xx “ is set as the following value , it can be as a special order. These order only can be used in complicated multi temperature profile program.

If **t xx = 0** : Controller will be paused at xx segment ( Hold) . Next program only can be run by a manual order ( touch A/M key )


If **txx = -(1-150)** Negative value is a control order, which let program stop running, or jump to other segment.

If **txx = -(Ax30+B)** , here B value is 1- 30. which indicates program will jump to the segment at B value  
When **A=0**, only execute segment jump function.  
When **A=1**, program will cut off power relay  
When **A=4, B=1**, Program will execute “ stop “ order


### (5) Run Temperature Control Program with Furnace

When temperature program set up ready, touch key  for two seconds, then display SV will show letter “run”, furnace will run automatically segment by segment according to program step by step.

Under furnace running state, “ Out “ indicator ‘s brightness will change based on power out value.

If you want the furnace to stop running temporarily, please push key  for two seconds, then display SV will show letter “ Hold”, the furnace enters “pause state “. In the “pause state”, controller will keep furnace temperature at the value when “pause” order was given, but time running is stop.

Under the “ Pause “ state, push key  for two seconds, SV display will shows “ run”. And furnace will start running again from the point where is paused.

If you want to stop running furnace, whatever under “ pause” or “ running “ state, you can push key  for two seconds, then, SV display shows “ stop”, furnace totally stop running and controller will be in “starting state”. If you want to run again, the program will start at the beginning step. If furnace temperature still is higher than “ C 02”, program will not run until

furnace cooling down to “ C 02”. In order to run faster, you can choose program run from “step 2” , or “step 3”.

## (6) Function Parameters Set Up and Revise

The following function parameters are preset in the temperature controller. They are very important for controlling furnace temperature stably and accurately. Unless you have enough experience, please don't change the preset parameters in the controller.

In order to change the function parameters, follow procedure as below:








- Touch  key for two second under “starting state”, display will enter parameter setting function
- Touch  key for one second again, PV display will shows symbol: “ M5 “ ( Fig. 11 ) , “ P” (fig. 12), “t” (fig. 13 ) , “Ctrl” ( fig 14) and “ LOC” (fig.15) separately.
- Using  and  key to change the value under diferent parameter setting.
- Push  key for two seconds, setting will go back to previous parameter.
- Puch Key , then push , Display will exist “parameter setting”.



Fig.11



Fig.12




Fig.13



Fig.14



Fig.15


**Table 2** lists the parameters and their meanings:

Parameter in Display Panel	Range to set	Parameter 's fuction	Preset value in the controller
<b>M5</b> Mataince parameter	0 -9999	Adjus temperature difference between set value and real value. M5 value is larger, adjust time is longer,, and M5 smaller time is shorter	( adjust between 200 – 500 )
<b>P</b> Speed parameter	1-9999	Adjustment rate in controller. P value increases adjustment faster, decrease, adjustment slower	( choose between 3- 10 )
<b>T</b> Delay time parameter	0 - 2000	Control temperature over shooting. t value smaller, temperature overshoot smaller, otherwise overshoot larger.	( 3-10)
<b>Ctrl</b> Control type	1, 2, 3, 4,	1= Auto tune from front panel 2= Auto tune first, then go to 3 or 3 3= built in Auto tune, can not be changed from front panel 4= more accurate auto tune	<b>3</b>
<b>LOC</b> Parameter lock	0 - 9999	Preset in controller. Please never chang	<b>808</b>

Again, only in the case that you find temperature controll is not stable during running or furnace the above parameters may consider to be adjusted.

Before adjust the parameters, you shall use “ **Auto-Tune**” function to achieve the best setting faster. The procedure is as the follows:



- Let furnace stay in a temperature that it is most important for you.
- Set Loc value to 2
- Let display return to “starting state “
- Push  key for two seconds, then front panel of controller will flash with letter “ AT”, wich means controller enter “ Auto-Tune” state.
- After Auto-Tune”, AT letter will disappear. Controller has choose all M5, P and t value automatically.
- You may repeat “ Auto-tune “ 2-3 times to achieve best result.
- After Auto-tune, please set Ctrl to 3.
- If temperature is still not stable after Auto-tune, then you may adjust M5, P, and t value manually.

In the spcial case, furnace can not run properly due to voltage varies in different area, you may need to adjust some parameters as the Table 3.  
 Agaian, The parameters have been preset according to our experience. Please don't adjust the following parameter unless you are very fimilar with the function of parameter

**Table 3.**

Parameter symbol in PV panel	Value preset in SV Panel	Function	Note
<b>HIAI</b>	1700	Max. Temp limit	
<b>Local</b>	200	Initial Temp limit	Limit output current beflow 200 oC
<b>dHAL</b>	999.9	Alarm in positive tolerance	
<b>dLAC</b>	999.9	Alarm in negative tolerance	
<b>dF</b>	0.3	Adjsutment difference	dF smaller, auto tune has higher accuracy
<b>Ctrl</b>	3	Control type	
<b>M5</b>		Mataince parameter	
<b>P</b>		Speed parameter	
<b>t</b>		Delay time parameter	
<b>Ctr</b>	1	Output period	Reflect controler's adjstment speed
<b>Sn</b>	6	Thermo cpuple type	B type T.C
<b>Dlp</b>	0	Position of decimal	
<b>DIL</b>	0	Display valve in Min.	
<b>DIH</b>	1800	Display value in Max.	
<b>Sc</b>	0.0	Main input shift and adjustment	Tolerance between input and sensor
<b>OP1</b>	1	Output type	Chhose 1 is output from 0 – 10 mA. Please make sure this value is compatible with controller
<b>OPL</b>		Output limit below 200 oC	This value will decide Max. output current when below 200 oC. Please choose 16 first. If found output current is too low, please increase the value up to 80. The most suitable value is the current meter show 120 – 140 A in initial heating stage
<b>OPH</b>	100	Output Up limit	Limit Max. output power. Max value is 130. Please the value as low as possible to avoid heating element is damaged
<b>ALP</b>	10	Alarm function	
<b>CF</b>	16	System fuction selection	82 means limit output current in two stages
<b>Addr</b>	1	Communication address	
<b>bAud</b>	9600	Communication	

		frequency	
dL	1	Inputdigital filter	dL value larger, measured temperature more stable, but reaction time is slow
run	27	Running condition	
Loc	0	Parameter revising grade	Value '0' woll lock will data that has been enter. " 808" will open lock to allow you to revise all parameters
EP1	M5		
EP2	P		
EP3	t		
EP4	Ctrl		
EP5	OPL	After adjusting, set to NoneE	
EP6	NOneE	After adjusting, set to NoneE	
EP7	NoneE		
EP8	NoneE		

In order to adjust the above parameters, you need do as the follows:  
 From function parameter state of " Loc" as Fig. 15, change "LoC" value from " 0" to "808" as Fig. 16



Fig .16



Fig .17



Fig .18






Fig .19



Fig. 20



Fig. 21

Then, you can revise the parameters from "HIAL" ( Fig 17) ---- "Sn " ----- " oPL " --" oPH" ( fig. 20) by The Key , ,  seperately. After change the parameter , and make sure all parameters are correct, then you need change " LOC" to '0" as Fig. 21. to lock all data without change.

## 6. Installation Procedures

Please follow the instructions as the below for furnace installtion

- Open shipping package to check if all compoments are good condition. If find any damage caused by shipping, please report it to our Corporation immediately by email.
- The furnace must be placed in flat surface to avoid vibration, where must keep from flammable and explosible materials.
- The furnace uses AC 220V / 4KW power. Please make sure that power source in your lab is enough to meet this power requirement.
- Ground wire ( double color --- green/white ) shall be connected to ground well. Shut down power if you don't use furnace to avoid any damage by accident
- Please insert thermal couple tube ( ceramic tube)in to furnace from backside of furnace, then tighten screw to fix thermal couple's position
- Connect thermal couple wires to controller. Please make sure that positive and negative polarties are connected correctly ( brown to positive; blue to negative. otherwise, controller can not work. Fig. 22).







Fig. 22

## 7. Instructions for Quick Start:

*Procedure for running furnace*

- Plug in power ( Green Power indicator is On, cooling fan run )
- Turn Power switch lock On, (Yudian 708P controller is On )
- Let 708P control displat is at " starting state ", e.g PV panel shows temperature value , and SV dispalys " stop". If controller is no at the state, touch  key , 708P controller shall be back to "starting state "
- Input temperature program. ( Please be advised that heating rate shall not be too fast in low temperature stage to avoid damage furnace )
- Push green " Turn On " power switch button.
- Push Key  on the controller and hold for 2 seconds, PV panel shows " Run", now furnace is running automatically

### Procedure for shut down furnace

- Push key  to make sure the controller is at “ stop “ state.
- Touch Red “ Turn-Off” button, shut down furnace power
- Turn lock to close position to cut off power to control panel
- If possible, close power switch from cable.
- End

## 8. Maintenance and Cautions

- a) When power on, if you can not hear a sound from cooling fan, please don't continue to operate. You must shut down power to check or replace the cooling fan.
- b) During furnace running, please don't touch furnace outside body to avoid any high temperature burn.
- c) MoSi<sub>2</sub> heating element is only suitable for using in air or inert gas environments. Other active gas, such as H<sub>2</sub>, Cl<sub>2</sub> and SO<sub>2</sub> will damage heating element.
- d) Please don't use the furnace at 400 – 700 °C temperature range for long time because MoSi<sub>2</sub> heating element will be easy to be oxidized in the temperature range.
- e) MoSi<sub>2</sub> heating element is very brittle. Please pay a great attention during moving and handling. Also, please avoid rapid heating and cooling to avoid the heating element broken. Max. 10 °C/min heating or cooling rate is suggested.
- f) Please check heating element for every three months to see if they are in good connecting condition. If connection get loose, please open case and tighten them properly.
- g) Please always keep inside chamber clean before running furnace to avoid contamination to your sample.
- h) Furnace must be used under following condition:  
Inside room at temperature between -10 – 75 °C  
Elevate < 1000 M, Humidity < 85%  
In the environment without vibration and conductible dust, explosive, flammable and corrosive gases
- i) MTI Corporation provides one year limited warranty from date that we shipped goods. If you find any defective caused by product's quality please feel free to contact us for replacement during warranty period. However, MTI Corp is not responsible for any damage or consequence damage caused by misuse.  
After warranty, MTI will continue to provide technical support and spare parts at a reasonable cost.

## 9. Trouble Shooting for typical Problems

Problems	Reason	Solution
Open Power Lock, no power indication	Fuse (4A) in control panel is broken	Check control panel, and replace fuse
Green Power indicator is off, but Red open circuit indicator is On	Fuse ( 50A) in main power circuit is broken	Open furnace front panel and replace the fuse
No current in meter , but has Max. Voltage	Heating element broken	Find broken heating rod, and replace it

Controller panel SV show " OraL"	Thermal Couples broken	Replace Thermal couples ( B type )
Controller panel SV show " HiaL"	Furnace temperature > 1700 °C, Protection from Alarm	Cool furnace down, and find reason why temperature is so high ( program setting may be wrong)
Power and heating element are OK, but furnace can't be controlled by program.	Controller or related circuit may damaged	Please inform manufacturer to check what is real problem
Program running, but furnace can not be heated, or real temperature is far behind the setting value	oPL or oPH values are too low due to local voltage lower or frequency different	Increase "oPL" and " oPH" value, until current meter show " 120A – 140 A", and program running smoothly

## 10. Attention

When the equipment is used for the first time, observe the ammeter please after it is set automatic operation. If the heated-current is too small, please turn the values of OPL on the parameter chart high properly until the heated-current is less than or equal to 140A!



## Packing List

NO.	NAME	UNIT	AMOUNT	INDEX
1	PA-1700TX high temperature furnace	Stand	1	
2	MoSi2 heating elements	Root	2	Largess
3	Double platinum-rhodium thermocouple	Pair	1	
4	Al <sub>2</sub> O <sub>3</sub> cushion block	Block	1	
5	Al <sub>2</sub> O <sub>3</sub> sprue	Block	1	
6	High temperature glove	Pair	1	Largess
7	Instruction	Copy	1	
8	Packing list	Copy	1	
9	Certificate of qualification	Copy	1	
10	Crucible pliers	Pair	1	Largess

## Eligible certificate

Spec and model: PA-1700TX

Serial number:

Date:

The product has been identified eligible, and is authorized to be sailed.

Quality inspection department: